

Systems

Low/High Density Timber

- *White spirits*

Key	
	Practical coverage in m ² /ltr per coat, depending on density of timber.
	Thinning %
	Drying time/Recoat after ... hrs
	Film thickness
	Application temperature °C
	Brush clean up

Directions

- Prior to starting, test white spirits on a small sample board or inconspicuous area to check for any unwanted reaction. This will also help you in devising the best method of application.
- Ensure all timber to be strip wiped has moisture content of 16% or lower.
- Ensure the timber surface to be strip wiped is cool to the touch. Do not apply in direct sun.
- All dressed timber should be lightly sanded with fine grade paper to remove machining marks, handprints, glue, etc. Always sand along the grain and never across. Remove sanding dust.
- Always use a lint free cloth when strip wiping timber with white spirits.
- Wipe surface of timber using a cloth dampened with white spirits. Ensure that the cloth is not over saturated.
- Vigorously rub the timber surface 4-5 times in one area and leave for 15 minutes to let the solvent evaporate completely before coating.
- For oily/resinous timbers wipe with white spirits 2-3 times at intervals of 15 minutes, the timber must be coated the same day.
- Timber will be ready for coating 15 minutes minimum after being strip wiped at the recommended application temperature of 5-30°C.

Please Note

- Every care is taken to ensure that the information provided in this data sheet is accurate. Jac Jay Limited is unable to guarantee results as it has no control over the conditions under which products are applied, the substrate or the application. The customer has to determine the suitability of the delivered products or information for its intended purpose.